



2. 4A 同步整流开关型移动电源管理方案

产品概述

VAS5185 是一款锂电池充电管理与升压 DC/DC 的单芯片专用 IC，其应用时仅需极少的外围器件，有效降低 BOM 成本，适用于单节锂离子/锂聚合物电池的移动电源充放电管理。它集成高效 1.0MHZ 同步 BUCK 锂电池充电管理，使用小尺寸的电感和电容最大可以达到 3.0A 的充电电流，自适应充电管理可以搭配各种形态的 5V 电源进行快速充电，可编程电池电压可以匹配不同形态的电芯达到电量的优化；升压 DC/DC 采用同步整流工作在 600KHz，适合推动 Qg 较小的功率 MOS，实现高放电效率，IC 本体温度低大幅提高可靠度，输出最大达到 5V/2.4A，透过采样电阻设置限流点可使输出达限流时维持恒定电流，不随电池电压与输出电压变化；支持智能判断负载插入和拔除，进行自动升压和自动关机，电池放电时电压低电与过温保护，输出过流/短路保护等电路，确保芯片和系统安全工作；集成 4 段的电池电量检测和显示，可以在充电还是升压放电的状态下有效地指示电池当前剩余的电量，负载补偿设计有效解决电量显示因为负载变化引起跳变或回弹的问题。手电 LED 可以输出最大 150mA 的电流，可通过按键控制手电的开关。

充电特点

- 10V 输入耐压
- 开关型充电电流
- 涓流，恒流，恒压和满充指示管理
- 1.0MHz 开关频率，支持 1.5uH 电感
- 高达 94%效率
- 支持 4.2V, 4.30V, 4.35V 电池
- 1.5hr 背景尾电流充电
- 自适应充电管理(VIN-DPM)
- 4 段 LEDs 电量显示(两种模式)
- 异常报错显示
- 支持边充边放
- 可启动手电功能
- 多重保护:
 - 6.6V 输入过压保护(OVP)
 - 电池短路与电池过压保护(BOVP)
 - 电池温度检测(50℃)

升压特点

- 小于 30uA 电池存放漏电流
- 600KHz 开关频率，共享电感(1.5uH)
- 5.10V 恒压输出, 5.82V 输出过压保护
- 高达 92%效率
- 2.4A同步整流输出
- 电池电压3.15V以下低电量提示
- 电池电压 2.80V 以下自动关闭输出
- 快速动态响应，支持全陶瓷电容应用
- 在升压模式下轻载自动关断
- 支持负载插入自动启动升压
- 4 段 LEDs 电量显示(带负载补偿)
- 过电流以 CC 模式输出，恒流点可调
- 多重保护:
 - 过电流限流输出/短路保护
 - 驱动外接 N 沟道 MOSFET 可完全断开 USB-A 口
 - 电池温度检测(60℃)

应用领域

- 移动电源
- 备用电源

封装

- TQFN4x4-24



Typical Application Circuits




Figure 1. Typical Application Schematic



PIN Configuration

Package	PIN-OUT
QFN-24	Pin configuration diagram for QFN-24 package. The diagram shows a 24-pin package with pins numbered 1 to 24. The pins are arranged in a 4x6 grid. The top row (pins 19-24) contains VCTR, VOUT, HD, BS, LX, and LD. The bottom row (pins 7-12) contains STAT, TL, LED1, LED2, LED3, and LED4. The left side (pins 1-6) contains VCC, REGN, GLMODE, ISET, NC, and BVST. The right side (pins 13-18) contains NDRV, CTRL, TS, VBAT, VSNS, and PGND. A central area is labeled PGND and AGND.



PIN Description


TQFN PIN NO.	Name	Description						
1	VIN	USB 或 AC 适配器输入。当 VIN 存在时，充电和电源管理路径工作，使用 10uF 陶瓷电容连接 VIN 与 PGND。						
2	REGN	5V 电源输出，通过一个 4.7uF 陶瓷电容旁路到地。						
3	GLMODE	电量显示模式选择引脚。						
		<table> <tr> <td>FLOAT</td><td>Hi</td><td>Lo</td></tr> <tr> <td>CHG: Wave(跑马灯) BOOST: ON</td><td>CHG: Flash(闪灯) BOOST: ON</td><td>CHG: Wave BOOST: ON(5sec) -> OFF</td></tr> </table>	FLOAT	Hi	Lo	CHG: Wave(跑马灯) BOOST: ON	CHG: Flash(闪灯) BOOST: ON	CHG: Wave BOOST: ON(5sec) -> OFF
FLOAT	Hi	Lo						
CHG: Wave(跑马灯) BOOST: ON	CHG: Flash(闪灯) BOOST: ON	CHG: Wave BOOST: ON(5sec) -> OFF						
4	ISET	快充电流设置，设置VSNS与VBAT之间的采样量以控制快充电流。 Lo: 15mV / FLT: 30mV / Hi: 45mV						
5	NC	No Connection.						
6	BVST	恒压电压设置。 Lo: 4.30V / FLT: 4.20V / Hi: 4.35V						
7	STAT	状态指示(Open drain)						
		<table> <tr> <td>Hi-Z</td><td>Low</td><td>Blinking</td></tr> <tr> <td>充电完成或休眠模式</td><td>充电中</td><td>异常</td></tr> </table>	Hi-Z	Low	Blinking	充电完成或休眠模式	充电中	异常
Hi-Z	Low	Blinking						
充电完成或休眠模式	充电中	异常						
8	TL	手电驱动输出。TL 引脚接地可以屏蔽手电功能。						
9,10, 11,12	LED1-4	电池电量显示。内置 1kohm 限流。						
13	NDRV	驱动外接 N 沟道 MOSFET 进行短路和漏电保护。升压启动 NDRV 为高电平，VOUT 电压过高过低或者过流检测发生时，NDRV 转低电平。待机时，NDRV 维持低电平。						
14	CTRL	按钮输入，连接按钮到地，此端口内部通过一个200kMQ的电阻上拉到电池。按按钮启动升压，长按按钮5秒可强制关闭升压；空载时，按按钮启动LED1-4电量显示，将持续5秒显示。充电与放电模式下，1.7秒以内连续两次按钮启动手电，再按一次关闭手电。						
15	NTC	电池温度采样端口，连接到电池温度调节器端子(NTC)，如果不连接到电池，可以连接至地以屏蔽 NTC 功能。推荐选料10K NTC (B-Constant=3950K)。						
16	VBAT	电池输入与充电恒压调节端口。电感连接至电池的正级需使用22uF低ESR和ESL陶瓷电容旁路到地。						
17	VSNS	充电电流与放电过流采样输入。通过 RSNS 电阻检测充放电电流。						
18	PGND	功率地。连接内部低端 MOSFET 驱动地。						
19	LD	低端 MOSFET 驱动输出。						
20	LX	外部开关与电感的连接端口，高端 MOSFET 驱动地。						
21	BS	Bootstrap 引脚输入，使用 22nF 陶瓷电容连接 LX 与 BS。						
22	HD	高端 MOSFET 驱动输出。						
23	VOUT	输出端口。通过低 ESR 和 ESL 陶瓷电容旁路到地，电容 44uF~470uF 可以稳定。						
24	VCTR	驱动外接P沟道MOSFET防止反向电流。电源输入时，VCTR为低电平，电源移除时，VCTR为高电平。						
25	EP	底部焊盘。连接到 PCB 的地。						



Order Information

Order Number	Package Type	QTY/Reel	Green Status	Operation temp range
VAS5185IJ24E	QFN24	2500	RoHS	-40 °C to 85°C

VAS5185 □ □ □ □ □



Absolute Maximum Ratings

Parameters	Maximum Ratings
VIN, VCTR, VOUT, STAT, TL LED1, LED2, LED3, LED4	-0.3V to 12V
LX	-2V to 10V
REGN, VBAT, CTRL, NDRV, VSNS BVST, GLMODE, TS, LD	-0.3V to 7V
HD, BS	-0.3V to 12V
GND, PGND	-0.3V to +0.3V
Junction temperature range	-40°C to +150°C
Storage temperature range	-65°C to +150°C
Lead Temperature	260°C
Maximum Power Dissipation	2W
ESD (HBM)	2000V



Electrical Characteristics

PARAMETERS		TEST CONDITIONS	MIN	TYP	MAX	UNITS
OPERATING CONDITIONS						
V _{VIN_OP}	VIN input voltage operating range during charging.		4.5		6	V
QUIESCENT CURRENT						
I _{IN}	Adapter supply current	V _{IN} =5V		1.5	2	mA
I _{BAT}	Battery discharge current	V _{BAT} =4.2V, standby mode		20	50	μA
CHARGE VOLTAGE REGULATION						
V _{BAT_REG}	BAT regulation voltage	Measured on BAT		4.2		V
	Charge voltage regulation accuracy	TJ = -20°C to 85°C	-1%		1%	
V _{BAT_ADJ}	Regulation voltage Adjustment	BVST=FLT,		4.20		V
		BVST=Lo		4.30		V
		BVST=Hi		4.35		V
CURRENT REGULATION						
I _{CHG}	Fast charge current	Programmable Mode(Max)		3.0		A
	Charge current regulation accuracy	TJ = -20°C to 85°C	-10%		10%	
V _{VSNS-VBAT}	Charge Current Full Scale Sense Voltage	ISET=FLT, RSNS=15mΩ		30		mV
		ISET=Lo, RSNS=15mΩ		15		mV
		ISET=Hi, RSNS=15mΩ		45		mV
	Output “fast charge” formula	V _{BAT_REG} > V _{BAT} > V _{LOWV} ;	V _{VSNS-VBAT} / RSNS			A
V _{IN_DPM}	Input voltage drop to reduce charge current	Measured on VIN		4.70		V
CURRENT REGULATION –PRE- CHARGE						
%PRECHG	Pre-charge current, default setting	V _{BAT} < V _{LOWV}		10		%I _{OUT-CC}
CHARGE TERMINATION						
%TERM	Termination threshold current, default setting	V _{BAT} > V _{RECHG}	5	10	15	%I _{OUT-CC}
t _{TERM_DEG}	Deglintch time termination (both edges)	V _{BAT} > V _{RECHG} and I _{CHG} < I _{TERM}		100		ms
BAT LOWV COMPARATOR						
V _{LOWV}	Precharge to fast charge transition threshold	Measured on BAT	2.90	2.95	3.00	V
RECHARGE COMPARATOR						
V _{RECHG}	Recharge threshold, below regulation voltage limit, V _{BAT_REG} -V _{BAT}	Measured on BAT	50	100	150	mV



PARAMETERS		TEST CONDITIONS	MIN	TYP	MAX	UNITS
BAT OVER-VOLTAGE COMPARATOR						
V _{BOV_RISE}	Battery over-voltage rising threshold	As percentage of V _{BAT_REG}		110		%
V _{BOV_FALL}	Battery over-voltage falling threshold	As percentage of V _{BAT_REG}		105		%
BAT SHORT COMPARATOR						
V _{BSHORT_RISE}	Battery short hysteresis	V _{BAT} rising		2.4	2.5	V
V _{BSHORT_FALL}	Battery short threshold	V _{BAT} falling	2.0	2.2		V
I _{BSHORT}	Battery short weakly pull high current	V _{BAT} < V _{BSHORT} , measure I _{BAT}	10	15	20	mA
INPUT OVER-VOLTAGE COMPARATOR (ACOV)						
V _{ACOV}	AC over-voltage rising threshold to disable charge	V _{IN} rising	6.2	6.4	6.6	V
V _{ACOV_HYS}	AC over-voltage falling hysteresis	V _{IN} falling		300		mV
INPUT UNDER-VOLTAGE LOCK-OUT COMPARATOR (UVLO)						
V _{UVLO}	AC under-voltage rising	Measure on V _{IN}		4.0		V
V _{UVLO-HSY}	AC under-voltage hysteresis	Measure on V _{IN}		300		mV
SLEEP COMPARATOR(REVERSE DISCHARGING PROTECTION)						
V _{SLEEP}	SLEEP mode threshold	V _{IN} – V _{BAT} falling		100		mV
V _{SLEEP_HYS}	SLEEP mode hysteresis	V _{IN} – V _{BAT} rising		200		mV
V _{CTRL_LO}	VCTRL output low voltage	V _{IN} < V _{BAT} +V _{SLEEP}			0.1	V
V _{CTRL_HI}	VCTRL output high voltage	V _{IN} > V _{BAT} +V _{SLEEP_HYS}	V _{OUT} -0.1			V
THERMISTOR COMPARATOR						
I _{TS}	NTC bias current		72	77	82	μA
V _{LTF}	Cold temperature threshold, TS pin voltage rising threshold	Charger suspends charge		3.0		V
V _{LTF_HYS}	Cold temperature hysteresis, TS pin voltage falling threshold	Charger recovery charge		2.6		V
V _{HTF}	Hot temperature TS pin voltage falling threshold	Charger suspends charge		300		mV
V _{HTF_HYS}	Hot temperature hysteresis, TS pin voltage rising threshold	Charger recovery charge		400		mV



PARAMETERS		TEST CONDITIONS	MIN	TYP	MAX	UNITS
V_{BT_HTF}	Boost mode, hot temperature TS pin voltage falling threshold	Booster suspends output		200		mV
$V_{BT_HTF_HYS}$	Boost mode, hot temperature hysteresis, TS pin voltage rising threshold	Booster recovery output		300		mV
$V_{TS_DISABLE}$	Disable TS pin threshold	$V_{TS} < V_{TS_DISABLE}$	30	50	70	mV
REGN REGULATOR						
V_{REGN_REG}	REGN regulator voltage	$V_{VIN} > 7V$	5.4	5.6	5.9	V
I_{REGN_LIM}	REGN current limit	$V_{REGN} = 0V, V_{VIN} > 7V$		100		mA
INTERNAL PWM						
F_{SW_CHG}	PWM Switching Frequency	Measure at LX	900	1000	1100	kHz
SAFETY TIMER						
$T_{PRE-CHARGE}$	Pre-charge timer		4822	5400	6048	Sec
$T_{TAPER-CHARGE}$	Taper-charge timer		4822	5400	6048	Sec
DC/DC STAGE						
V_I	Input voltage range	V_{BAT} input voltage	2.8		4.5	V
V_{OUT}	Output voltage range	Measure at V_{OUT}	5.00	5.10	5.20	V
V_{OUT_VO}	Output overvoltage threshold	V_{OUT} rising, NDRV off		6.0		V
$V_{OUT_VO_HYS}$	Output overvoltage threshold	V_{OUT} falling, NDRV on		5.82		V
$t_{VOUT_OV_DEG}$	Output overvoltage deglitch	$V_{OUT} > V_{OUT_VO}$ to NDRV off		2		ms
V_{OUT_UV}	Output under-voltage threshold	V_{OUT} falling, NDRV off		4.15		V
$V_{OUT_UV_HYS}$	Output under-voltage threshold	V_{OUT} rising, NDRV on		4.25		V
$t_{VOUT_UV_DEG}$	Output under-voltage deglitch	$V_{OUT} < V_{OUT_UV}$ to NDRV off		20		μs
V_{OUT_SHORT}	Output short threshold	V_{OUT} falling, Boost off		3.8		V
f_{SW}	Oscillator frequency		550	600	650	kHz
I_{STDBY}	Standby current	$V_{BAT} = 4.2V$, Boost off		20	50	μA
OUTPUT CURRENT REGULATION						
$V_{VBAT-VOUT1}$	Battery output current limit sense voltage @ $V_{BAT}=3V$	$RSNS=15m\Omega$		75		mV



PARAMETERS		TEST CONDITIONS	MIN	TYP	MAX	UNITS
V _{VBAT-VOUT2}	Battery output current limit sense voltage @ V _{BAT} =4V	RSNS=15mΩ		56		mV
	Battery output “current limit” formula	4.20V > V _{BAT} > V _{VBAT_UVLO} ;	V _{VBAT-VSNS} / RSNS			A
CONTROL STAGE						
V _{BAT_LOW}	Battery low to boost enter standby mode	VBAT voltage decreasing	3.08	3.15	3.22	V
F _{LOW_FLASH}	Battery low, LED1 flash frequency	VBAT<V _{BATLOW} , LED1 start flash frequency	1.2	1.4	1.6	Hz
V _{BAT_UVLO}	Battery low voltage lockout	VBAT voltage decreasing, Boost off	2.75	2.8	2.85	V
V _{NDRV_OL}	NDRV output low voltage				0.1	V
V _{NDRV_HI}	NDRV output high voltage		VOUT -0.1			V
V _{IL}	CTRL logic low threshold		0.4			V
V _{IH}	CTRL logic high threshold				VOUT -0.7	V
t _{CTRL_DEG}	CTRL logic low deglitch time			15	50	mS
LED INDICATOR & TORCH LIGHT						
V _{LED_OL}	LEDs output low voltage	LEDs sink 1mA			1	V
F _{LED_CHG}	LEDs wave frequency at charge mode	LED N-1 to N switch frequency	1.2	1.4	1.6	Hz
T _{LED_HOLD}	Gauge on hold time at boost mode	CTRL goes low, LEDs on to LEDs off GLMODE=Lo		5		Sec
T _{MANUALOFF}	CTRL cont. low to boost enter standby mode deglitch	CTRL goes cont. low to boost turn off		3		Sec
T _{TL_EN}	Effective interval for two CTRL low pulses to enable or disable torch light		1.2	1.7	2	Sec
I _{TL_LIM}	TL sink current limit	Torch light on, VTL =2V		150		mA
I _{NOLOADDOFF}	No load detection current			80		mA
T _{LEDOFF}	No load to LEDs off delay	No load to gauge LEDs turn off		5		Sec
T _{NOLOADOFF}	No load to Boost off delay	No load to Boost turn off		15		Sec



Operation State Diagram




Figure 3. State Diagram

Gauge Light Indication

MODE	VBAT	LED1	LED2	LED3	LED4	STAT
CHARGE	BAT < 3.75V	WAVE	WAVE	WAVE	WAVE	ON
	3.75V < BAT < 3.90V	ON	WAVE	WAVE	WAVE	ON
	3.90V < BAT < 4.15V	ON	ON	WAVE	WAVE	ON
	4.15V < BAT	ON	ON	ON	WAVE	ON
	Termination	ON	ON	ON	ON	OFF
BOOST (No Load)	BAT < 2.8V	OFF	OFF	OFF	OFF	OFF
	2.80V < BAT < 3.32V	Blink	OFF	OFF	OFF	OFF
	3.32V < BAT < 3.55V	ON	OFF	OFF	OFF	OFF
	3.55V < BAT < 3.82V	ON	ON	OFF	OFF	OFF
	3.82V < BAT < 4.00V	ON	ON	ON	OFF	OFF
	4.00V < BAT	ON	ON	ON	ON	OFF
BOOST (Load)	BAT < 2.8V	OFF	OFF	OFF	OFF	OFF
	2.80V < BAT < 3.05V	Blink	OFF	OFF	OFF	OFF
	3.05V < BAT < 3.42V	ON	OFF	OFF	OFF	OFF
	3.42V < BAT < 3.69V	ON	ON	OFF	OFF	OFF
	3.69V < BAT < 3.82V	ON	ON	ON	OFF	OFF
	3.82V < BAT	ON	ON	ON	ON	OFF
STANDBY		OFF	OFF	OFF	OFF	OFF



CTRL Control

Mode	Function	One pulse	Double pulse <1.7sec	One more pulse during Torch ON	Pulse > 5Sec during Boost ON
CHARGE	BOOST	OFF			
	GAUGE	ON			
	TORCH	OFF	ON or OFF	Delay 1.7sec then OFF	OFF
	NDRV ON	ON			
BOOST VBAT>3.0V VIN<VBAT	BOOST	ON Keep 30Secs ON then OFF (if no load)	ON	ON	OFF
	GAUGE	ON Keep 6sec ON then OFF(if no load)	ON	ON	OFF
	TORCH	OFF	ON or OFF	Delay 1.7sec then OFF	OFF
	NDRV ON	ON	ON	ON	OFF

- CTRL can turn flashlight no during charging mode, but the boost converter keep off and the load (USB-A) is disconnected from battery power.
- In standby mode, click the CTRL button can start the BOOST and battery power indicator, such as the no-load input, the power indicator off after 5 seconds, BOOST turn off automatically after 15 seconds.
- If battery voltage is lower than 2.8V, click the button will not weak BOOST up, the LED1 flash 5secs then off, the power bank keep stay at the standby mode.
- Double-click the button to turn on or off the flashlight, and power display always on when flashlight function is activated, in this mode, click the button again, flashlight off automatically after 1.7 seconds delay.
- In boost mode, press button 3 seconds can manually turn off BOOST, and disconnect the load circuit.

Application Information

◆ Charge Management

1. Typical Operation Theory

The charger of VAS5185 is optimized for charging 1-cell Li-ion or Li-polymer batteries. It charges a battery with constant current (CC) and constant voltage (CV) profile. In CV mode, if charge current reaches 1/10 constant current threshold, fuel gauge 4 LEDs are turned on. The typical charge profile is illustrated as below.




Figure 4. Typical Charging Profile

2. Battery Voltage Regulation

The VAS5185 offers a high accuracy voltage regulator for the charging voltage. Battery regulation voltage could be adjusted by setting BVST level for 4.2V, 4.30V and 4.35V selection, see “Electrical Characteristics Table” for the detail.

3. Battery Current Regulation

The ISET input sets the maximum charging current. The ISET level selects charge current sense voltage as 15mV, 30mV or 45mV, see “Electrical Characteristics Table” for the detail. The equation for charge current is:

$$I_{CHG} = \frac{V_{VSNS} - V_{BAT}}{R_{SNS}}$$

Give a 15mΩ RSNS and set ISET level to logic low for a 30mV $V_{VSNS} - V_{BAT}$ will be able to get 2.0A charge current, for instance.

4. Battery Pre-charge Current Regulation

If the battery voltage is below the V_{BSHORT} threshold, the switching loop stop and the VAS5185 applies a weak 15mA charge current to the battery. This weak charge feature is intended to revive deeply discharged cells. If the battery voltage is greater than V_{BSHORT} and less than V_{LOWV} threshold, the battery will be charged by pre-charge cycle with a 1/10 of fast charge current. If battery is not reached V_{LOWV} within 90 minutes of initiating pre-charge, the charger turns off and a FAULT is indicated on the status pins.

5. Input Over Voltage Protection

Input OVP provides protection to prevent device damage due to high input voltage. The threshold of input OVP is 6.4V typ., once input above threshold, the charger is disabled and STAT indicated FAULT.

6. Input Voltage Regulation

The input voltage can be limited in order to avoid overloading of DC adapter or USB power source, when the voltage on VIN pin drops and hits the threshold voltage of 4.7V, the charging current will be decreased and input voltage will be clamped to this value.

7. Charge Termination

The charger monitors the charging current during the voltage regulation phase. Termination is detected when the charge taper down to 1/10 of the fast charge rate.

8. Re-Charge

A new charge cycle is initiated when one of the following conditions occurs:

- The battery voltage falls below the recharge threshold
- A power-on-reset (POR) event occurs

9. Timers

As a safety backup, the charger also provides an internal fixed 90 minutes pre-charge safety timer. And fixed 90minutes taper charge timer for additional charge capacity, it start once termination is happened.

10. Soft-Start Charger Current

The charger automatically soft-starts the charger regulation current every time the charger goes into fast-charge to ensure there is no overshoot or stress on the output capacitors or the power converter.

11. Temperature Qualification

The TS pin output a zero TC current to bias a negative temperature coefficient thermistor (NTC) which connect to AGND. The controller continuously monitors battery temperature by measuring the voltage between the TS pin and AGND, it compares this voltage against its internal thresholds to determine if charging is allowed. To initiate a charge cycle, the battery temperature must be within the VLTF to VHTF thresholds. If battery temperature is outside of this range, the controller suspends charge and waits until the battery temperature is within the VLTF to VHTF range. The controller suspends charge by turning off the PWM MOSFETs. In the Boost mode, battery cell



temperature qualification still works with a different VHTF threshold, typically more 10 degree C range compare to charge cycle. A 10K NTC with B-Constant around 3950k is recommended for application.

◆ Boost Converter

1. Typical Operation Theory

The VAS5185 integrates a boost converter powered by a one-cell Li-Ion or Li-polymer battery. The converter generates a stable 5.10V output voltage, it provides high efficient power conversion with two external low on resistance NMOSFETs and is capable of delivering output currents up to 2.4 A at 5 V while a supply voltage down to 3.0 V. The implemented boost converter is based on a fixed frequency, pulse-width- modulation (PWM) controller.

2. Soft Start

The boost automatically soft-starts the switching current to load to ensure there is no overshoot or inrush stress on the output capacitors, the boost switch current limit is set to 50% of its normal value to avoid high peak current at battery during soft-start period. When the output voltage is reached, the voltage regulator takes control and switch current limit is set back to 100%.

3. Over-current and Short Protection

The maximum peak current in the boost switch is set by the resistance of RSNS and sense voltage $V_{VBAT-VSNS}$, the unique input and output voltage compensation peak current detection help to control maximum IOUT in constant current mode regardless of input/output voltage variation if it reached to maximum tripped value. The sense voltage $V_{VBAT-VSNS}$ limit the boost input current at 3.0V VBAT, with the gradual increase in VBAT voltage, current limit will be gradually reduced, in order to achieve the first stage input constant power control, the controller continuously monitors VOUT voltage add compensation to sense current to achieve the second stage output constant current control. In other words, with $V_{VBAT-VSNS}$ and RSNS decide the current limit if VBAT equal to 3.0V, consider converting efficiency can get output current limit tripped point. With this setup, the VBAT and VOUT voltage vary will change current limit very small, can be regarded as a constant current mode.

If the output current reaches the over-current point, output current begins to start limiting and then voltage fall down, when the voltage dropped below 3.8V, NDRV shut down immediately and disconnect the output, but boost does not latch-off, but if output consistently below 4.25V for more than 2ms, the boost circuit locked and needed to be restart.

4. Over-voltage protection

The controller continuously monitors the output voltage, if the voltage is higher than 6.0V, NDRV disconnect the load immediately, PWM control will stop output until the output sinks to 5.8V below, NDRV will re-connect the load in order to protect the device.

5. Automatic Load-in Detection

Design an external resistor connect USB-A ground to system ground, when a load is connected to USB-A port, the load and ext. resistor construct a resistor divider from VOUT to ground. If the resistance of load is small enough to pull divided voltage high and turn on NMOS, the CTRL could be pulled low to enable boost converter. For example, set ext. resistor to 100k Ω , and a load with less than 200k Ω resistance is connected, the divided voltage from a 3.0V VOUT can as high as 1.0V and be able to turn a NMOS on.



6. Light Load Automatic Shutdown


The boost converter detects average current to load, if average current fall below 80mA for 5sec., the fuel gauge LEDs are turning off and start 15secs go standby timer. Once 30secs timer expired, and average current never go back above 80mA, then the boost enter automatic shutdown.

◆ Fuel Gauge LEDs Indication

The VAS5185 integrated with four LED constant current drive ports for intelligent battery level indication, the chip built-in state lock function to prevent indicate the status of instability. See “Gauge Light Indication” table for detail fuel gauge level and LEDs behavior.




Tape and Reel Information







Package Information



Top View



Bottom View



Side View

	MIN.	NORM.	MAX.
A	0.700	0.750	0.800
	0.800	0.850	0.900



Classification Reflow Profiles

Profile Feature	Pb-Free Assembly
Preheat & Soak Temperature min (T _{smin}) Temperature max (T _{smax})	150°C
Time (T _{smin} to T _{smax}) (ts)	200°C 60-120 seconds
Average ramp-up rate (T _{smax} to T _p)	3°C/second max.
Liquidous temperature (T _L)	217°C
Time at liquidous (t _L)	60-150 seconds
Peak package body temperature (T _p)*	Max 260°C
Time (t _p)** within 5°C of the specified classification temperature (T _c)	Max 30 seconds
Average ramp-down rate (T _p to T _{smax})	6°C/second max.
Time 25°C to peak temperature	8 minutes max.




Figure 21. Classification Profile



CAUTION

Storage Conditions

1) This product should be used within 12 months after delivered. Store in manufacturer's package keeping the seal of aluminum coated baggage or tightly re-closed box with the following conditions.

[Temperature: 8°C ... 30°C, Humidity: 30% ... 70% R.H.]

2) Keep the seal of aluminum coated baggage immediately before usage.

3) After breaking the seal of aluminum coated baggage, this product should be used within 1 week on the following conditions.

[Temperature: ≤ 30°C, Humidity: ≤ 60% R.H.]